Installation: Fix carbon filter into the unit and turn it in clockwise direction. Repeat the same on the other side.

